SONY
make.believe

MPK-WG

Marine Pack

Take your Cyber-shot with you on your underwater journeys. Dive down to 132 feet and take spectacular photos, Sweep Panorama shots and movies.

Bullets

- Take amazing underwater shots up to 132 feet (40m) deep
- Works with the underwater photo mode of your Cyber-shot® camera
- Takes advantage of the underwater movie mode of the Cyber-shot® DSC-W350 camera
- Basic camera functions available while in use
- LCD hood and hand strap included

Features

Dive Down

Take amazing underwater shots up to 132 feet (40m) deep

Sweep Panorama

Take amazing underwater Sweep Panorama shots

Movie Mode

Takes advantage of the movie mode of DSC-W570 Cyber-shot® camera

Basic Camera Functions

Basic camera functions available while in use

Hood and Hand Strap

LCD hood and hand strap included

Specifications

Weights and Measurements	
Depth (Approx.)	Up to 132 ft (40m)
Dimensions (Approx.)	
Dimensions (Approx.)	5 7/8 x 4 1/2 x 3 5/8in (148mm x 112mm x 89mm)
Weights and Measurements	
Weight (Approx.)	1 lb 1oz (480g)
General	
Function	ON/OFF (Power), Shutter, Playback, Zoom (W/T), Mode, Home, Menu, Disp, Flash, Self-timer, Delete
Material	Plastic and glass
Operating Conditions	
Storage Temperature	-4 to +140°F(-20 to +60°C)
Water Resistance	O-ring, buckle
Hardware	
Microphone	No
Accessories	
Supplied Accessories	Hand strap LCD hood Diffuser Front attachment F-E (for DSC-W570) Rear attachment R-BC (for DSC-W570) Grease O-ring Spacer Printed documentaion Reflex prevention ring Weight

SONY
make.believe

© 2011 Sony Electronics Inc. All rights reserved. Reproduction in part or in whole is prohibited without prior written consent by Sony. Sony and like.no.other are trademarks of Sony. Features and specifications are subject to change without notice. All Weights and measures are approximate. /Updated: January 26, 2012